



**AcousticsFirst**<sup>®</sup>

C O R P O R A T I O N

2247 Tomlyn Street, Richmond, VA 23230

PH: (804) 342-2900 FX: (804) 342-1107

[www.AcousticsFirst.com](http://www.AcousticsFirst.com)

## Installation tips for acoustical foam products

When applying the tiles, the substrate must be smooth, clean, dry, solid and free from dust, oil and wax residues. Substrates that do not meet these conditions should first be treated with water-based primers.

3M Spray 74 can be used to glue tiles to either ceiling or wall surfaces that meet the above conditions.

Follow directions on can – note that both the surface of the tile and the substrate should be sprayed before adhering.

Clean, white gloves are helpful in keeping the tiles clean during installation.

Tiles should be stored in the area where they are to be used for 24 hours before installation. This is due to possible humidity fluctuations that may cause tiles to swell.

A vacuum cleaner may be used for periodic cleaning.