



POLYURETHANE FOAM INSTALLATION GUIDE

- Cut adhesive tube end to produce a 1/4 bead.
- First apply a 1/4 bead of adhesive around the entire perimeter of the panel approximately 1" away from the edge.
- Second, apply a 1/4 bead of adhesive from opposite corners through the center of the panel to create an X.
- When the adhesive has been applied, quickly place and press the panel piece firmly onto the surface and hold for 5 seconds .
- Next, pull the panel away from the surface for approximately 1 minute to allow the adhesive to become tacky. Then, gently but firmly, press the panel back into position.
- When cutting panels, best results are achieved when cutting is done on the back or flat side. Be sure to lay panels on a clean surface before cutting.
- An electric carving knife is a good tool for cutting and trimming.

