



Rotofast Snap-On Anchor

Rotofast Snap-on Anchors are a secure and fast solution for acoustical panel installation. For ceilings or walls, the Rotofast Snap On anchor is the answer.

Installation Instructions



Rotofast Snap-On

Everything you need to install a panel in **5 EASY STEPS**.



1

Screw Rotofast Snap-On Anchors into the back of the panel using the Rotofast driver tool.



2

Insert marking plugs into the Snap-On anchors.



3

Push panel against wall to mark anchor locations.



4

Screw ratchets to wall at marked locations. (#8 screws recommended)



5

Firmly push panel onto ratchets to complete installation.

